

Place drilling template on inside (unpainted side) of tow hook cover.