



WEATHERBEATER® FLOOR LINERS

PT #1419

CARE AND USE INSTRUCTIONS

Thank you for selecting an **WeatherBeater™** Floor Liners from Husky Liners Inc. Your new liner is **custom molded to fit your specific vehicle's floor board. The** liner is made to take the place of your factory floor mats. *For correct fit, it is necessary to remove the factory floor mats before installing your new floor liner.* However, do not remove the factory-installed carpeting.

Your liner is made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liner is with a damp cloth or sponge and soap and water. Windex®, 409® and ArmorAll® type cleaners work as well.

INSTALLATION INSTRUCTIONS FOR YOUR 3RD SEAT LINER MODELS WITH 2ND ROW BUCKET SEATING



TO EASE INSTALLATION OF YOUR NEW LINERS, MOVE BOTH SECOND ROW SEATS TO THEIR MOST FORWARD POSITION. WITH THIS DONE, INSTALL THE LINERS AS SHOWN ABOVE. ONCE YOU HAVE INSTALLED YOUR LINERS, REPOSITION THE SEATS AS DESIRED.

IF YOUR VEHICLE HAS A CONSOLE BETWEEN THE SECOND ROW OF SEATS, YOUR LINER WILL NEED TRIMMED TO ALLOW THE CORRECT FIT. PLEASE SEE THE BACK OF THIS PAGE FOR DETAILS.



WEATHERBEATER® FLOOR LINERS

PT #1419

TO TRIM YOUR LINER FOR MODELS WITH A CONSOLE BETWEEN THE SECOND ROW SEATS, USE THE MOLDED IN HORIZONTAL TRIM GROOVE AS YOUR TRIMMING GUIDE. A PAIR OF HEAVY SHEARS OR A UTILITY KNIFE WORK WELL FRO TRIMMING. NOT YOU WILL

