



WEATHERBEATER™ FLOOR LINERS

PT #2622

CARE AND USE INSTRUCTIONS

Thank you for selecting a WeatherBeater™ Cargo Liner from Husky Liners. Your new cargo liner is custom molded to fit your Kia Sportage. Upon removal from the box your liner will not completely unroll and lay flat. This is normal and only temporary. Just place the liner on the floor or in the cargo area of your vehicle with a weight in each corner (a book works well). After about 15 minutes, your liner will remain flat. In colder climates this “relaxing” may take longer; moving the liner to a heated area and letting it lay face-down in a flat position will speed the process.

Your liner is manufactured using an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liner is with a damp cloth or sponge. If using a cleaner, 409® or Glass Plus® work well. Do not use Armor All®, Son-of-a-Gun® or similar items as these products make the liner slick.



IF YOUR SPORTAGE IS EQUIPPED WITH A SUBWOOFER, YOUR LINER WILL NEED TRIMMED TO ACHIEVE THE CORRECT FIT. A TRIM GROOVE IS MOLDED INTO THE LINER TO GUIDE THE NECESSARY TRIM. HEAVY SHEARS OR A UTILITY WORK WELL FOR TRIMMING.