



WEATHERBEATER™ FLOOR LINERS

PT #2989

CARE AND USE INSTRUCTIONS

Thank you for selecting a WeatherBeater™ Cargo Liner from Husky Liners. Your new cargo liner is custom molded to fit your Subaru Forester. Upon removal from the box your liner will not completely unroll and lay flat. This is normal and only temporary. Just place the liner on the floor or in the cargo area of your vehicle with a weight in each corner (a book works well). After about 15 minutes, your liner will remain flat. In colder climates this “relaxing” may take longer; moving the liner to a heated area will speed the process.

Your liner is manufactured using an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liner is with a damp cloth or sponge. If using a cleaner, 409® or Glass Plus® work well. Do not use Armor All®, Son-of-a-Gun® or similar items as these products make the liner slick.

CARGO LINER INSTALLATION INSTRUCTIONS FOR YOUR SUBARU FORESTER



IF YOUR FORESTER HAS THE OPTIONAL HARMAN KARDON, YOU WILL NEED TO TRIM YOUR LINER TO ACCOMMODATE THE SUBWOOFER LOCATED BEHIND THE PASSENGER SIDE WHEEL WELL. TO TRIM, REFER TO THE INSTRUCTIONS ON THE BACK OF THIS PAGE.



WEATHERBEATER™ FLOOR LINERS

PT #2989

HUSKY LINER PART #29891 SHOWN TRIMMED TO ACCOMMODATE THE OPTION HARDAN KARDON SOUND SYSTEM'S SUBWOOFER. TO TRIM USE A UTILITY KNIFE OR HEAVY SHEARS AND FOLLOW THE TRIM STEP LOCATED NEXT TO THE RAISED RIB (SEE BELOW). THE STEP IS MORE EASILY SEEN ON THE UNDERNEATH (BACK SIDE) OF THE PART.

