



X-ACT CONTOUR

FLOOR LINERS

CARE AND USE INSTRUCTIONS – PN: 55761

Thank you for selecting X-act Contour™ Floor Liners from Husky Liners Inc. Your new 3rd seat floor liner is custom molded to fit your specific vehicle's floor board. The liner is made to take the place of your factory floor mats.

For correct fit, it is necessary to remove the factory floor mats before installing your new floor liners. However, *do not remove the factory-installed carpeting.*

Your liner is made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liner is with a damp cloth or sponge and soap and water. Windex®, 409® and ArmorAll® type cleaners work as well.



TO EASE INSTALLATION OF YOUR THIRD SEAT LINER, SLIDE BOTH 2ND ROW SEATS TO THEIR MOST FORWARD POSITION. WITH THIS DONE, INSTALL THE LINER, POSITIONING IT AS SHOWN IN THE IMAGE ABOVE. NOTE THAT THE TONGUE PORTION THAT EXTENDS FORWARD BETWEEN THE 2ND ROW BUCKET SEATS TUCKS BEHIND THE BACK OF THE 2ND SEAT LINER. ONCE THE LINER IS INSTALLED, REPOSITION THE 2ND ROW SEATS AS NEEDED.

ONCE IF YOUR PALISADE HAS 2ND ROW BENCH SEATING, THE TONGUE PORTION OF THE LINER WILL NEED TRIMMED. PLEASE SEE THE BACK OF THIS PAGE FOR TRIMMING INSTRUCTIONS.

55761

IF YOUR VEHICLE HAS 2ND ROW BENCH SEATING YOU WILL NEED TO TRIM YOUR LINER TO ACHIEVE THE CORRECT FIT. TO TRIM, USE A UTILITY KNIFE OR HEAVY SHEARS AND, FOLLOWING THE MOLDED IN TRIM GROOVE IN THE PART, REMOVE THE TONGUE SECTION AS SHOWN BELOW.

